BaByliss® PRO

STYLIST TOOLS



PERFECT CURL™ MKII

BAB2666U

European Registered Design Number: 003992692-0001
UK Patent Number(s): 2 242 393, 2 455 716, 2 620 075, 2 651 260, 2 893 832, 2 515 980, 2 858 529, 2 521 783

BaByliss PRO
STYLIST TOOLS

BABYLISS PRO PERFECT CURL MKII

Create three different types of curl in seconds with the new BaByliss PRO Perfect Curl MKII featuring ground-breaking auto-curl technology enabling the creation of three types of curl formations at the touch of a button; tight, defined or loose waves.

The advanced curl management system automatically adjusts the central barrel, carefully controls the hair tension and precisely regulates the heat and time to create the perfect curl, whichever curl mode you choose.

TECHNICAL SPECIFICATION

- Ceramic curl chamber for beautiful, smooth curls
- Fully automatic curl management system with three curling modes
- 3 Heat settings; 230˚C, 200˚C and 180˚C for long lasting results
- Curl direction control for a uniform or natural finish
- Advanced heating system delivers precision-regulated temperature control
- Ultra-fast heat up and instant heat recovery
- 20 minute sleep mode function
- On/off switch
- Automatic shut off
- 2.8m salon length swivel cord
- 6 month guarantee

SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for future reference.

IMPORTANT CHILD SAFETY

WARNING! Polythene bags over product or packaging may be dangerous. To avoid danger of suffocation, keep wrapper away from babies and children. This bag is not a toy.

WARNING! THIS APPLIANCE GETS HOT!

- **ALWAYS** keep out of reach of children (during and after use and whilst cooling).
- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children.
- Do not use on very young children.

IMPORTANT SAFETY




- Do not use the appliance in the bathroom.

WARNING! Do not use this appliance near water contained in basins, bathtubs or other vessels.

- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped. In the event of damage, discontinue use immediately. Contact the Conair Customer Care Line (refer to ‘UK After Sales Service’ section for further information).

- Do not use the appliance if the lead is damaged. In the event of lead damage, discontinue use immediately. If the lead is damaged it must be replaced by the manufacturer. Return the appliance to the Customer Care Centre (refer to ‘UK After Sales Service’ section for further information). No repair must be attempted by the consumer.
- Do not leave the appliance unattended when switched on or plugged in.
- During use do not place the appliance on any heat sensitive surface.
- Take care to avoid the hot surface of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- In the event the appliance is left switched on, it will automatically shut off after 60 minutes. If you wish to continue using the appliance after this time, simply slide the switch to the off position, then slide the switch to the relevant setting to turn the power on.
- This appliance should not be used by adults who’s reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- After use, do not wrap the lead around the appliance as this may cause damage. Instead, coil loosely by the side of the appliance.
- This product complies fully with all appropriate EU and UK Legislation and the Standards relevant to this type and class of appliance. We are an ISO9001:2015 certified company that continually evaluates our Quality Management System performance. If you have any queries regarding product safety and compliance, please contact the Conair Customer Care Line. (refer to ‘UK After Sales Service’ section for further information).

OPERATING FEATURES



OPERATING INSTRUCTIONS

Always ensure hair is clean, dry and combed through before styling. When creating defined and loose curls take sections of hair that are no bigger than 3cm wide. When creating tight curls, the smaller the section the tighter the curl. When working with naturally curly or longer length hair, we advise you to use even smaller sections. The result will depend on the section size and the temperature selected.

CURL MODES

Simply select the curl mode to choose from tight curls, defined curls or loose curls. The advanced curl management system will automatically adjust the central barrel and carefully control the hair tension to suit the chosen curl mode.

Tight Curls

The slim barrel is automatically activated and the soft grip tension control guides ensure the hair is wrapped securely around the slim barrel for effortless tight curls. For tighter curls, we recommend to take smaller sections of hair.

Defined Curls

The slim barrel is activated and the automatic tension control ensures the hair is wrapped softly around the slim barrel then relaxed for defined, natural-looking curls.

Loose Curls

The large barrel is automatically deployed and the hair carefully wrapped around the barrel for beautiful loose curls.

HEAT SETTINGS

There are 3 heat settings to select from; 230˚C, 200˚C, 180˚C. We recommend always starting with the lowest temperature setting and increasing the level of heat as required.

- Setting ⋮ (230°C) - for thick or wavy hair
- Setting ⋮ (200°C) - for normal textured hair
- Setting • (180°C) - for delicate, fine or coloured hair


CURL DIRECTION CONTROL (Right/Left/Auto)

Use the Curl Direction Control to create either a uniform or natural finish.


- When styling the left side of the hair, slide the curl direction switch to the left position ↺.
- When styling the right side of the hair, slide the curl direction switch to the right position ↻. This ensures that the curl sits towards the face on both sides of the head and will give a more uniform style.
- For a more natural look, select the auto setting ⟲. This will alternate the direction after each curl.


INSTRUCTIONS FOR USE

- Plug the styler into a suitable mains socket.
- Chose your desired curl by pressing the curl mode button until the light is illuminated under your chosen curl type.
- Press the heat setting button until your required temperature is selected (230˚C, 200˚C, 180˚C).
  NOTE: Always start with a lower temperature setting and increase gradually if required.
- The styler is ready for use when the chosen temperature light has stopped flashing.
- Select the curl direction by sliding the control to position ↺, ↻ or ⟲.
- Ensure hair is clean, dry and combed through.
- Separate a section of hair that is no bigger than 3cm (Diagram A).
  NOTE: When creating defined and loose curls take sections of hair that are no bigger than 3cm wide. When creating tight curls, the smaller the section the tighter the curl. When working with naturally curly or longer length hair, we advise you to use even smaller sections.





- Please note the styler must be positioned into the hair with the open part of the curl chamber facing towards the head. (Diagram B).






- Position the styler where you want the curl to start. The hair section must be held straight, and placed neatly through the centre of the styler. (Diagram C & D).






- Once the hair is in place, let go of the hair section and close the handle to allow the hair to be automatically taken into the curl chamber. (Diagram E).



NOTE: If you continue to hold the hair section after closing the handle then the Perfect Curl MKII will stop and beep to indicate that you must release the tension on the hair. If you have taken too much hair, or hair is not neatly going through the centre of the appliance, the Perfect Curl MKII will again stop and beep to indicate a problem. This safety feature ensures that there will be no tangles.

- The hair is automatically drawn into the ceramic curl chamber where it is softly held and heated from all directions to effortlessly form the curl.
- The automatic beep indicator will start as soon as the handles are closed together. There will be 5 individual beeps. Hold the styler still with the handles closed together until the end of the individual beeps. There will then be four quick beeps in succession. This indicates that you can remove the styler from the hair.
- It is very important that you release the handles fully, and then gently pull the styler away from the head to free the hair and reveal the curl (Diagram F). **NOTE:** Always release the handles first to let the curl free; if you pull away before you open the handles, the curl will be straightened out.



- To allow the curl to set, do not comb or brush the hair until it cools.
- Repeat around the head until all sections of hair have been curled.

SLEEP MODE

This appliance has an automatic sleep mode feature. If the appliance is not used for more than 20 minutes the temperature will automatically drop down to 150°C. If you wish to continue using the appliance after this time, simply close then release the handles and it will return to the temperature setting you were using it on.

AUTO SHUT OFF

This appliance has an automatic shut off feature for added safety. If the appliance is switched on for more than 60 minutes continuously, it will automatically switch off. If you wish to continue using the appliance after this time, simply slide the switch to the off position and then power back on.

MAINTENANCE

IMPORTANT: Do not immerse the appliance in water or other liquids.
To help keep your styler in the best possible condition follow the steps below:

- Do not wrap the lead around the appliance; instead coil the lead loosely by the side of the appliance.
- Do not use the appliance at a stretch from the power point.
- Always unplug after use.

UK GUARANTEE
The Conair Group Ltd, Unit 3, Waterfront Business Park, Fleet, GU51 3TW.

This BaByliss PRO appliance is guaranteed for professional use for 6 months and is only valid within the United Kingdom.

Exclusions
This guarantee will no longer be valid meaning that The Conair Group Ltd will not be liable to repair or replace your product where:

1.) The appliance has been used on a voltage supply other than that which is marked on the product, or advised within this instruction booklet.
2.) The appliance has been purchased from an unauthorised stockist*.
3.) Repairs or alterations have been attempted by unauthorised persons.
4.) The failure of the appliance is a direct result of misuse.
5.) The failure is a result of not following the instructions for use.

This guarantee does not cover any cosmetic damage due to misuse of the product nor any damage to persons or property that occurs because of product misuse.

*unauthorised stockists include, but are not limited to online auction sites, private sellers and those selling second hand goods, refurbished products etc.

Please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com for further information on authorised stockists.

It is important to retain your proof of purchase. We recommend attaching your receipt to this page.

Even where a refund may be applicable, no refund will be provided without a valid receipt or proof of purchase, we will only be able to offer a repair or replacement service. Please note this does not apply if the product was purchased directly from The Conair Group Ltd.

Guarantees on replacement products run from the original purchase date or date of delivery, whichever is later, and **not** from the date of replacement.

This guarantee is an additional benefit and does not affect your statutory rights as a consumer.

If you have any queries regarding this guarantee please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com.

UK AFTER SALES SERVICE
For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail your enquiry to ukinfo@conair.com.

Return address:
Customer Care Centre
Conair Logistics
Unit 4, Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW

Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.

Please note this Instruction Booklet is not the guarantee.

SAFE DISPOSAL



The ▬ symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

BaByliss

CE DECLARATION OF CONFORMITY

We the undersigned, hereby certify the conformity of the following product:

Type of product	: Curling Iron curl secret
Type Number	: F87a
Trademark	: BaByliss / CPL
with following characteristics	: 230V~ 50-60Hz 42W
Country of origin	: China

Within the essential requirements of the CE Directives:

2014/30/EU	ElectroMagnetic Compatibility Directive
2014/35/EU	Low Voltage Directive
2011/65/EC	RoHS Directive
2009/125/EC	Ecodesign Directives implemented by the Commission Regulations (EC) No. 1275/2008 and (EC) No. 278/2009 (where applicable) amended by 2008/28/EC
2006/42/EC	Machinery directive

In accordance with the following standards:

LVD	EN 60335-1	2012	A11; AC (2014)
	EN 60335-2-23	2003	A1; A11; A2
(including EMF)	EN 62233	2008	
Ecodesign	EN 50564	2011	
EMC	EN 55014-1	2006	A1; A2
	EN 55014-2	2015	
	EN 61000-3-2	2014	
	EN 61000-3-3	2013	

CE mark first affixed: October 2017

BABYLISS FACO S.P.R.L (authorised by BABYLISS S.A.R.L and Conair Group Ltd)
The Managing Director
Olivier Smal

Signature:
Date:

CE

BaByliss FACO s.p.r.l. - 25, Avenue de l'Indépendance - B-4020 WANDRE - BELGIQUE - ☎ : (0032) 04 345 60 60 - FAX : (0032) 04 345 60 88
Reg. Com. Lg. 136.914 - B.C.E. 0412.537.139 - T.V.A. BE 0412.537.139 - I.N.S. 340-0551883-88